

HI92150: USB 2.0 to RS232 Adapter

To allow our users access to the latest version of Hanna Instruments PC compatible software, we made the products available for download at <http://software.hannainst.com>. Select the product code and click **Download Now**. After download is complete, use the **setup.exe** file to install the software.

Driver Installation

If required, download USB 2.0 driver from <http://software.hannainst.com>.

***Note:** For Windows[®] 98, ME, NT, follow the displayed Help instructions.*

Using HANNA Application Softwares

1. Plug the **HI92150** into a USB port of your PC and wait for 10 seconds.
2. Connect the instrument to the **HI92150** adapter using a HANNA serial cable (**HI920010** or **HI920011**) or IR interface.
3. Run the HANNA application software on your PC.
4. Set the proper communication port and baud rate.
5. Click the "Connect" option.

***Note:** Do not disconnect the HI92150 from the PC while the application software is running.*

Dear Customer,

Thank you for choosing a HANNA product.

Please read carefully the operating instructions before using this device.

If you need additional technical information, do not hesitate to e-mail us at **tech@hannainst.com**.

This adapter is in compliance with the CE directives.

QC INSPECTION

Appearance

Functioning

Inspector: _____

Date: _____