

IST92150 R2 12/07

- Instruction and QC card for HI 92150 RS232/USB converter
- Dimensions: 9 x 9 cm
- Black printing on paper board

HI 92150: USB 2.0 to RS232 Adapter

Driver Installation

1. Insert the supplied USB driver CD.
2. Press "Install drivers".

Note: For Windows® 98, ME, NT, follow the displayed Help instructions.

Using HANNA Application Softwares

1. Plug the **HI 92150** into a USB port of your PC and wait for 10 seconds
2. Connect the instrument to the **HI 92150** adapter using a HANNA serial cable (HI 920010 or HI 920011) or IR interface
3. Run the HANNA application software on your PC
4. Set the proper communication port and baud rate
5. Click the "Connect" option

Note: Do not disconnect the **HI 92150** from the PC while the application software is running



IST92150R2 12/07

Side 1

Dear Customer,

Thank you for choosing a HANNA product.

Please read carefully the operating instructions before using this device.

If you need additional technical information, do not hesitate to e-mail us at tech@hannainst.com.

This adapter is in compliance with the CE directives.

QC INSPECTION

Appearance

Functioning

Inspector: _____

Date: _____

Side 2