

HI 92150: USB 2.0 to RS232 Adapter

Driver Installation

1. Insert the supplied USB driver CD.
2. Press "Install drivers".

Note: For Windows® 98, ME, NT, follow the displayed Help instructions.

Using HANNA Application Softwares

1. Plug the **HI 92150** into a USB port of your PC and wait for 10 seconds.
2. Connect the instrument to the **HI 92150** adapter using a HANNA serial cable (**HI 920010** or **HI 920011**) or IR interface.
3. Run the HANNA application software on your PC.
4. Set the proper communication port and baud rate.
5. Click the "Connect" option.

Note: Do not disconnect the **HI 92150** from the PC while the application software is running.



IST92150 03/15

www.hannainst.com

HI 92150: USB 2.0 to RS232 Adapter

Driver Installation

1. Insert the supplied USB driver CD.
2. Press "Install drivers".

Note: For Windows® 98, ME, NT, follow the displayed Help instructions.

Using HANNA Application Softwares

1. Plug the **HI 92150** into a USB port of your PC and wait for 10 seconds.
2. Connect the instrument to the **HI 92150** adapter using a HANNA serial cable (**HI 920010** or **HI 920011**) or IR interface.
3. Run the HANNA application software on your PC.
4. Set the proper communication port and baud rate.
5. Click the "Connect" option.

Note: Do not disconnect the **HI 92150** from the PC while the application software is running.



IST92150 03/15

www.hannainst.com

HI 92150: USB 2.0 to RS232 Adapter

Driver Installation

1. Insert the supplied USB driver CD.
2. Press "Install drivers".

Note: For Windows® 98, ME, NT, follow the displayed Help instructions.

Using HANNA Application Softwares

1. Plug the **HI 92150** into a USB port of your PC and wait for 10 seconds.
2. Connect the instrument to the **HI 92150** adapter using a HANNA serial cable (**HI 920010** or **HI 920011**) or IR interface.
3. Run the HANNA application software on your PC.
4. Set the proper communication port and baud rate.
5. Click the "Connect" option.

Note: Do not disconnect the **HI 92150** from the PC while the application software is running.



IST92150 03/15

www.hannainst.com

HI 92150: USB 2.0 to RS232 Adapter

Driver Installation

1. Insert the supplied USB driver CD.
2. Press "Install drivers".

Note: For Windows® 98, ME, NT, follow the displayed Help instructions.

Using HANNA Application Softwares

1. Plug the **HI 92150** into a USB port of your PC and wait for 10 seconds.
2. Connect the instrument to the **HI 92150** adapter using a HANNA serial cable (**HI 920010** or **HI 920011**) or IR interface.
3. Run the HANNA application software on your PC.
4. Set the proper communication port and baud rate.
5. Click the "Connect" option.

Note: Do not disconnect the **HI 92150** from the PC while the application software is running.



IST92150 03/15

www.hannainst.com

Dear Customer,
Thank you for choosing a HANNA product.
Please read carefully the operating instructions before using this device.
If you need additional technical information, do not hesitate to e-mail us at **tech@hannainst.com**.
This adapter is in compliance with the CE directives.

QC INSPECTION	
Appearance	<input type="checkbox"/>
Functioning	<input type="checkbox"/>
Inspector: _____	
Date: _____	

Dear Customer,
Thank you for choosing a HANNA product.
Please read carefully the operating instructions before using this device.
If you need additional technical information, do not hesitate to e-mail us at **tech@hannainst.com**.
This adapter is in compliance with the CE directives.

QC INSPECTION	
Appearance	<input type="checkbox"/>
Functioning	<input type="checkbox"/>
Inspector: _____	
Date: _____	

Dear Customer,
Thank you for choosing a HANNA product.
Please read carefully the operating instructions before using this device.
If you need additional technical information, do not hesitate to e-mail us at **tech@hannainst.com**.
This adapter is in compliance with the CE directives.

QC INSPECTION	
Appearance	<input type="checkbox"/>
Functioning	<input type="checkbox"/>
Inspector: _____	
Date: _____	

Dear Customer,
Thank you for choosing a HANNA product.
Please read carefully the operating instructions before using this device.
If you need additional technical information, do not hesitate to e-mail us at **tech@hannainst.com**.
This adapter is in compliance with the CE directives.

QC INSPECTION	
Appearance	<input type="checkbox"/>
Functioning	<input type="checkbox"/>
Inspector: _____	
Date: _____	

IST92150 03/15

- Instruction and QC card for HI 92150 RS232/USB converter
- Dimensions: 9 x 9 cm
- Black printing on paper board

HI 92150: USB 2.0 to RS232 Adapter

Driver Installation

1. Insert the supplied USB driver CD.
2. Press "Install drivers".

Note: For Windows® 98, ME, NT, follow the displayed Help instructions.

Using HANNA Application Softwares

1. Plug the **HI 92150** into a USB port of your PC and wait for 10 seconds.
2. Connect the instrument to the **HI 92150** adapter using a HANNA serial cable (**HI 920010** or **HI 920011**) or IR interface.
3. Run the HANNA application software on your PC.
4. Set the proper communication port and baud rate.
5. Click the "Connect" option.

Note: Do not disconnect the **HI 92150** from the PC while the application software is running.



IST92150 03/15

www.hannainst.com

Side 1

Dear Customer,

Thank you for choosing a HANNA product.

Please read carefully the operating instructions before using this device.

If you need additional technical information, do not hesitate to e-mail us at tech@hannainst.com.

This adapter is in compliance with the CE directives.

QC INSPECTION

Appearance

Functioning

Inspector: _____

Date: _____

Side 2