# **INSTRUCTION MANUAL**

# <u>HI 961</u>04

# pH, Chlorine & Cvanuric Acid ISM

Dear Customer

Thank you for choosing a Hanna Instruments product. Please read this instruction manual carefully before using these instruments. This manual will provide you with the necessary information for correct use of these instruments, as well as a precise idea of their versatility. If you need additional technical information do not besitate to e-mail us at tech@hannainst.com or view our worldwide contact list at www.hannainst.com

#### **Preliminary examination:**

Please examine this product carefully. Make sure that the instrument is not damaged. If any damage has occurred during shipment, please notify your Dealer.

Each HI 96104 Ion Selective Meter is supplied complete with:

- Two Sample Cuvettes and Caps
- 9V Battery
- Instruction Manual

Note: Save all packing material until you are sure that the instrument works correctly. Any defective item must be returned in its original packina.

#### $\dot{i}$ For more details about spare parts and accessories see "Accessories".

Ted	hnical	specifications:
Total C	pH hlorine hlorine ric Acid	6.5 to 8.5 0.00 to 5.00 mg/L 0.00 to 5.00 mg/L 0 to 80 mg/L
Resolution	0.01 mg/	L under 3.50 mg/L Chlorine L above 3.50 mg/L Chlorine yanuric Acid
Accuracy p Free Chlorin Total Chlorin Cyanuric Ac	ne ±0.0 ne ±0.0	pH @ 25 °C  3 mg/L ±3% of reading @ 25 °C  3 mg/L ±3% of reading @ 25 °C mg/L ±15% of reading @ 25 °C
Light Source	Tungsten	lamp
Light Detector	Silicon Pl filter @	notocell with narrow band interference 525 nm
causes a the USEP reaction For <u>Cyan</u> The reac	red tint in A method o with reagen <u>uric Acid</u> : A tion betwo	method. The reaction with reagents the sample. For <u>Chlorine</u> : Adaptation of and Standard Method 4500-Cl G. The tts causes a pink tint in the sample. daptation of the turbidimetric method. seen cyanuric acid and the reagent ension in the sample.
Environment		°C (32 to 122 °F); 6 RH non-condensing
Battery Type	1 x 9 Vo	lt
Auto-Shut off		of non-use in measurement mode;
		our of non-use in calibration mode; reading reminder.
Dimensions	with last	

## Functional description:

# HANNA 2.00. 59 HI 96104 PI PH PI TOTAL CL PI FREE CL PI CTANURE ACD RANGE CAL ZERO READD (4) (5) (6) (7) (8) (2)(3)

- 1. RANGE/GLP/ key: press to change the paramter, press and hold for three seconds to enter GLP mode. In *calibration mode*, press to edit the date and time
- 2. CAL CHECK key: press to perform the validation of the meter, or press and hold for three seconds to enter *calibration mode*.
- 3. **ZERO/CFM** key: press to zero the meter prior to measurement, to confirm edited values or to confirm factory calibration restore.
- 4. READ/►/TIMER key: In measurement mode, press to take a measurement, or press and hold for three seconds to start a pre-programmed countdown prior to measurement. In GLP mode, press to view the next screen.
- 5. ON/OFF kev: to turn the meter on and off.
- 6. Liquid Crystal Display (LCD)
- 7. Cuvette alignment indicator
- 8. Cuvette holder

## DISPLAY ELEMENTS DESCRIPTION:



- 1. The measuring scheme (lamp, cuvette, detector), appears during different phases of zero or reading measurement
- 2. Error messages and warnings
- 3. The battery icon indicates the charae state of the battery
- 4. The houralass appears when an internal check is in progress
- 5. Status messaaes
- 6. The chronometer appears when the reaction timer is running
- 7. The month, day and date icons appear when a date is displayed
- 8. Four digit main display
- 9. Measuring units
- 10. Four digit secondary display

# **Errors and warnings:**

#### ON ZERO READING:



P2

69

Err

Err

Light High: There is too much light to perform a measurement. Please check the preparation of the zero cuvette.

Light Low: There is not enough light to perform a measurement. Please check the preparation of the zero cuvette

No Light: The instrument cannot adjust the light level. Please check that the sample does not contain any debris.

#### ON SAMPLE READING:



Inverted Cuvettes: The sample and the zero cuvette are inverted



Zero: A zero reading was not taken. Follow the instructions of the measurement procedure for zeroing the meter.



Under Ranae: A blinking "0.00" indicates that the sample absorbs less light than the zero reference. Check the procedure and make sure you use the same cuvette for reference (zero) and measurement



Over Ranae: A flashina value of the maximum concentration indicates an over range condition. The concentration of the sample is beyond the programmed range; dilute the sample and

AL		
	E .	
	it n i	r
	STDLOW	
		כס

**indard Low:** The standard reading is less an expected.



Standard High: The standard reading is higher than expected.

#### OTHER ERRORS AND WARNINGS



the analysis cell. Ensure that the cuvette cap is present.

Cooling Lamp: The instrument waits for the lamp to cool down.



www.hannainst.com

re-run the test.

# DURING CALIBRATION PROCEDURE


CALIDINATION	1 I KULL
	Sta
rr	thar
" on	

















Cap Error: Appears when external light enters



Battery Low: The battery must be replaced

Dead Battery: This indicates that the battery is dead and must be replaced. Once this indication is displayed, normal operation of the instrument will be interrupted. Change the battery and restart the meter.

#### Measurement procedure:

1 • Turn the meter on by pressing ON/OFF. 2. When the beeper sounds briefly and the LCD displays dashes and "P1" (pH), "P2" (Free Chlorine), "P3" (Total Chlorine) or "P4" (Cvanuric Acid), the meter is ready. The code that appears on the secondary display is the one of the last selected parameter. If necessary, press **RANGE/GLP/** to change parameter. The blinking "ZERO" indicates that the instrument needs to be zeroed first.

- **3** Fill the cuvette up to the 10 mL mark with unreacted sample and replace the cap.
- **4** Place the cuvette into the holder and ensure that the notch on the cap is positioned securely into the groove.
- 5 Press ZERO/CFM and the lamp, cuvette and detector icons will appear on the display. depending on the measurement phase.
- 6 After a few seconds the display will show "-0.0-". The meter is now zeroed and ready for measurement.
- 7 Remove the cuvette.
- 8 Add the specific test reagent for each parameter:

pH: 5 drops of HI 93710-0 Free Chlorine: 1 packet of HI 93701-0 Total Chlorine: 1 packet of HI 93711-0 For Cvanuric Acid fill a beaker with 25 mL of sample, add 1 packet of HI 93722-0

and swirl gently. Fill a second cuvette with 10 mL of reacted sample.

- 9. Replace the cap and swirl the solution for 20 seconds.
- **10** Replace the cuvette into the holder and ensure that the notch on the cap is positioned securely into the groove.


11 • Press and hold **READ**/>/TIMER for three seconds. The display will show the countdown prior to measurement. The beeper is playing a beep at the end of countdown period. Alternatively, wait for:

Free Chlorine: 1 minute Total Chlorine: 2 minutes and 30 seconds Cvanuric Acid: 45 seconds Then press **READ**/>/TIMER. For pH press **READ**/>/TIMER directly



In all cases the lamp, cuvette and detector icons will appear on the display, depending on the measurement phase.

12 • The instrument directly displays the pH measured value or the concentration in ma/L of free chlorine, total chlorine or cvanuric acid on the LCD, depending on the selected parameter.



#### INTERFERENCES for FREE CHLORINE and TOTAL CHLORINE

- Bromine Iodine Chlorine dioxide Ozone and Oxidized forms of Managnese and Chromium.
- In case of water with alkalinity areater than 250 ma/L CaCO, or acidity areater than 150 ma/L CaCO., the color of the sample may develop only partially, or may rapidly fade. To resolve this, neutralize the sample with diluted HCl or NaOH.
- In case of water with hardness areater than 500 ma/L CaCO<sub>2</sub>, shake the sample for approximately 2 minutes after adding the powder reagent.

## Validation and Calibration procedures

Warning: Do not validate or calibrate the instrument with standard solutions other than the Hanna CAL CHECK<sup>™</sup> Standards, otherwise erroneous results will be obtained

For accurate validation and calibration results, please perform tests at room temperature (18 to 25 °C: 64.5 to 77.0 °F).

#### **ℓ** Use the Hanna CAL CHECK<sup>™</sup> cuvettes (see "Accessories") to validate or calibrate instruments.

#### VALIDATION

- Note: The validation is performed only for the selected parameter. For full validation of the instrument, the following procedure must be performed for each parameter.
- 1. Turn the meter on by pressing ON/OFF.
- **2** When the beeper sounds briefly and the LCD displays dashes, the meter is ready.
- **3** Place the CAL CHECK<sup>™</sup> Standard Cuvette A into the cuvette holder and ensure that the notch on the cap is positioned securely into the groove.
- 4 Press ZERO/CFM and the lamp, cuvette and detector icons will appear on the display, depending on the measurement phase.
- **5** After a few seconds the display will show "-0.0-". The meter is now zeroed and ready for validation.
- 6 Remove the cuvette
- **7** Place the specific **CAL CHECK<sup>™</sup>** Standard Cuvette B into the cuvette holder, for: pH: **B**, **HI 96710-11** 8 Free Chlorine: **B**. **HI 96701-11** Total Chlorine: B, HI 96711-11 Cyanuric Acid: **B**, **HI 96722-11** Ensure that the notch on the cap is positioned securely into the groove.



Fβ

Validation **v** 

, Ø

ZERO

•• P1

- [] [] -

<● P1

Pi

Ø

4-5

- "CAL CHECK" will appear on the display. depending on the measurement phase. **9**• At the end of the measurement, the display will show the validation standard value.
  - The reading should be within specifications as reported in the CAL CHECK<sup>™</sup> Standard Certificate If the value is found to be out of specifications, please check that the cuvettes are free from finaerprints, oil or dirt and repeat validation. If results are still found to be out of specifications, then recalibrate the instrument.

8. Press CAL CHECK key and the lamp.

cuvette and detector icons together with

# CALIBRATION

- Note: It is possible to interrupt the calibration procedure at any time by pressina CAL CHECK or ON/OFF kevs. When calibrating, only the selected range is affected
- 5 1 • Turn the meter on by pressing ON/OFF. **2**• When the beeper sounds briefly and the
- LCD displays dashes, the meter is ready. **3**• To change the range, simply press RANGE/GLP/
- 4. Press and hold CAL CHECK for three seconds to enter *calibration mode*. The display will show "CAL" during calibration procedure. The blinking "**7ERO**" asks for instrument zeroing.
- **5** Place the CAL CHECK<sup>™</sup> Standard Cuvette A into the cuvette holder and ensure that the notch on the cap is positioned securely into the aroove.
- 6 Press ZERO/CFM and the lamp, cuvette and detector icons will appear on the display. depending on the measurement phase.
- **7** After a few seconds the display will show "-0.0-". The meter is now zeroed and ready for calibration. The blinking "READ" asks for reading calibration standard.
- 8. Remove the cuvette.
- pH: B, HI 96710-11
- Total Chlorine: B. HI 96711-11 Cvanuric Acid: B. HI 96722-11 Ensure that the notch on the cap is positioned securely into the groove.
- **10** Press **READ**/►/TIMER and the lamp, cuvette and detector icons will appear on the display, depending on the measurement phase.

**11** • After measurement the instrument will show for three seconds the CAL CHECK™ Standard value.

12-14

0 108

20 188

0908

2009

ZERO CFM

Stor

PI

Last

Calibration

Date **v** 

0 108

FEÂL

2009

65

15-16

17

18

19

1

2

2009

**≥≥o**oos\_

- Note: If the display shows "STD HIGH", the standard value was too high. If the display shows "STD LOW" the standard value was too low. Verify that all CAL CHECK<sup>™</sup> Standard Cuvettes. A and B are free from finaerprints or dirt and that they are inserted correctly.
- 12 Then the date of last calibration (e.g.: "01.08.2009") appears on the display, or "01.01.2009" if the factory calibration was selected before. In both cases the year number is blinking, ready for date input.
- **13** Press **RANGE/GLP/**▲ to edit the desired vegr (2009-2099). If the key is kept pressed. the year number is automatically increased.
- 14 When the correct year has been set, press ZERO/CFM or READ/ /TIMER to confirm. Now the display will show the month blinking.
- **15** Press RANGE/GLP/▲ to edit the desired month (01-12). If the key is kept pressed, the month number is automatically increased.
- 16 When the correct month has been set, press **ZERO/CFM** or **READ**/ /TIMER to confirm. Now the display will show the day blinking.
- **17** Press **RANGE/GLP/**▲ to edit the desired day (01-31). If the key is kept pressed, the day number is automatically increased.
- Note: It is possible to change the editing from day to year and to month by pressina RFAD/►/TIMFR
- 18 Press ZERO/CFM to save the calibration date.
- 19 The instrument displays "Stor" for one second and the calibration is saved.
- 20 The instrument will return automatically to *measurement mode* by displaying dashes on the ICD

## GLP

In GLP mode, the last calibration date can be verified and the factory calibration can be restored.

#### LAST CALIBRATION DATE

- 1 Press and hold RANGE/GLP/▲ for three seconds to enter GIP mode. The calibration month and day will appear on the main display and the year on the secondary display.
- **2** If no calibration was performed, the factory calibration message, "F.CAL" will appear on the main display and the instrument returns to *measurement mode* after three seconds.

#### FACTORY CALIBRATION RESTORE

It is possible to delete the calibration and restore factory calibration.

- 1 Press and hold RANGE/GLP/▲ for three 2 seconds to enter GIP mode
- **2** Press **READ**/►/TIMER to enter the factory calibration restore screen. The instrument asks for confirmation of user calibration delete





**4**• The instrument briefly indicates "donE" upon restoration of factory calibration prior to returning to *measurement mode*.

#### **Batterv management**

To save the battery, the instrument shuts down after 10 minutes of non-use in *measurement mode* and after 1 hour of non-use in *calibration* mode

If a valid measurement was displayed before auto-shut off the value is displayed when the instrument is switched on. The blinking "ZERO" means that a new zero has to be performed.

One fresh battery lasts for around 750 measurements, depending on the liaht level.

The remaining battery capacity is evaluated at the instrument's startup and after each measurement.

The instrument displays a battery indicator with three levels as follows:


- 3 lines for 100 % capacity
- 2 lines for 66 % capacity
- 1 line for 33 % capacity

• The battery icon is blinking if the capacity is under 10 %. If the battery is empty and accurate measurements can't be taken any more, the instrument shows "dEAd bAtt" and turns off. To restart the instrument, the battery must be replaced with a fresh one. To replace the instrument's battery, follow the steps:

- Turn the instrument off by pressing ON/OFF.
- Turn the instrument upside down and remove the battery cover by turning it counterclockwise.



- Extract the battery from its location and replace it with a fresh one.
- Insert back the battery cover and turn it clockwise to close.




- Cuvette B into the cuvette holder, for:
- Free Chlorine: **B**. **HI 96701-11**





















70

Pl



71

Pi

Calibration **v** 

P |

ı B

Ś

CFM

«•• P1

- [].[] -

Factorv Calibration Restore **v** 





Accessories

<u>Reagent sets</u>		
HI 93701-01	Reagents for 100 free chlorine tests	
HI 93701-03	Reagents for 300 free chlorine tests	
HI 93710-01	Reagents for 100 pH tests	
HI 93710-03	Reagents for 300 pH tests	
HI 93711-01	Reagents for 100 total chlorine tests	
HI 93711-03	Reagents for 300 total chlorine tests	
HI 93722-01	Reagents for 100 cyanuric acid tests	
HI 93722-03	Reagents for 300 cyanuric acid tests	
OTHER ACCESSORIES		
HI 96701-11 (	<b>CAL CHECK™</b> Standard Cuvettes for Free Chlorine (1 set)	
	NI CHECKIM Standard Curvettee for pH (1 cot)	

HI 96710-11 CAL CHECK<sup>™</sup> Standard Cuvettes for pH (1 set)

- HI 96711-11 CAL CHECK<sup>™</sup> Standard Cuvettes for Total Chlorine (1 set)
- HI 96722-11 CAL CHECK<sup>™</sup> Standard Cuvettes for Cvanuric Acid (1 set)
- HI 721310 9V battery (10 pcs.)
- HI 731318 Cloth for wiping cuvettes (4 pcs.)
- HI 731331 Glass cuvettes (4 pcs.)
- HI 731335 Caps for cuvettes (4 pcs.)

HI 93703-50 Cuvette cleaning solution (230 mL)

#### Warrantv

HI 96104 is warranted for two years against defects in workmanship and materials when used for its intended purpose and maintained according to the instructions

This warranty is limited to repair or replacement free of charae.

Damages due to accident, misuse, tampering or lack of prescribed maintenance are not covered

If service is required, contact your dealer. If under warranty, report the model number, date of purchase, serial number and the nature of the failure. If the repair is not covered by the warranty, you will be notified of the charaes incurred.

If the instrument is to be returned to Hanna Instruments, first obtain a Returned Goods Authorization Number from the Customer Service Department and then send it with shipment costs prepaid. When shipping any instrument, make sure it is properly packaged for complete protection.

To validate your warranty, fill out and return the enclosed warranty card within 14 days from the date of purchase.

#### **Recommendations for Users**

Before using these products, make sure that they are entirely suitable for your specific application and for the environment in which they are used.

Operation of these instruments may cause unacceptable interferences to other electronic equipments, this requiring the operator to take all necessary steps to correct interferences

Any variation introduced by the user to the supplied equipment may degrade the instrument's EMC nerformance

To avoid damages or burns, do not put the instrument in microwave oven. For your and the instrument's safety do not use or store the instrument in hazardous environments.

Hanna Instruments reserves the right to modify the design, construction or appearance of its products without advance notice.

For additional information, contact your dealer or the nearest

Hanna Customer Service Center. To find the Hanna Office in your area, visit our web site

www.hannainst.com

S

5104

1/90

